



# **ZigBee Cluster Library Level Control Cluster (0x0008) Test Specification Errata Version 1.0**

ZigBee Document 16-02860-005

July 3rd, 2017

Sponsored by: ZigBee Alliance

Accepted by                      This document has been accepted for release by the ZigBee Alliance Board of Directors

Abstract                              This document describes the certification tests for devices which implement the ZCL Level Control cluster.

Keywords                            ZCL, Level control, cluster, errata

---

Copyright © ZigBee Alliance, Inc. (1996-2017). All rights reserved.

508 Second Street, Suite 206 Davis, CA 95616 - USA

<http://www.zigbee.org>

Permission is granted to members of the ZigBee Alliance to reproduce this document for their own use or the use of other ZigBee Alliance members only, provided this notice is included. All other rights reserved. Duplication for sale, or for commercial or for-profit use is strictly prohibited without the prior written consent of the ZigBee Alliance.

1

2

This page is intentionally blank

## 3 Notice of use and disclosure

4 Copyright © ZigBee Alliance, Inc. (1996-2017). All rights Reserved. This  
5 information within this document is the property of the ZigBee Alliance and its use  
6 and disclosure are restricted.

7 Elements of ZigBee Alliance specifications may be subject to third party intellectual  
8 property rights, including without limitation, patent, copyright or trademark rights  
9 (such a third party may or may not be a member of ZigBee). ZigBee is not responsible  
10 and shall not be held responsible in any manner for identifying or failing to identify  
11 any or all such third party intellectual property rights.

12 No right to use any ZigBee name, logo or trademark is conferred herein. Use of any  
13 ZigBee name, logo or trademark requires membership in the ZigBee Alliance and  
14 compliance with the ZigBee Logo and Trademark Policy and related ZigBee policies.

15 This document and the information contained herein are provided on an “AS IS” basis  
16 and ZigBee DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED,  
17 INCLUDING BUT NOT LIMITED TO (A) ANY WARRANTY THAT THE USE  
18 OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OF  
19 THIRD PARTIES (INCLUDING WITHOUT LIMITATION ANY  
20 INTELLECTUAL PROPERTY RIGHTS INCLUDING PATENT, COPYRIGHT OR  
21 TRADEMARK RIGHTS) OR (B) ANY IMPLIED WARRANTIES OF  
22 MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE OR  
23 NONINFRINGEMENT. IN NO EVENT WILL ZIGBEE BE LIABLE FOR ANY  
24 LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OF DATA,  
25 INTERRUPTION OF BUSINESS, OR FOR ANY OTHER DIRECT, INDIRECT,  
26 SPECIAL OR EXEMPLARY, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL  
27 DAMAGES OF ANY KIND, IN CONTRACT OR IN TORT, IN CONNECTION  
28 WITH THIS DOCUMENT OR THE INFORMATION CONTAINED HEREIN,  
29 EVEN IF ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. All  
30 Company, brand and product names may be trademarks that are the sole property of  
31 their respective owners.

32 The above notice and this paragraph must be included on all copies of this document  
33 that are made.

34

35

36

37

This page is intentionally blank

38

## Revision history

| Revision | Date                             | Details  | Editor        |
|----------|----------------------------------|--|---------------|
| 000      | November, 2016                   | Resolved CCB 2151, 2242, 2268 and 2269.                              | Phil Jamieson |
| 001      | November 14 <sup>th</sup> , 2016 | Updated document number.   | Phil Jamieson |
| 002      | November 23 <sup>rd</sup> , 2016 | Added further resolution for CCB 2269.                               | Phil Jamieson |
| 003      | January 23 <sup>rd</sup> , 2017  | Resolved CCB 2285. Resolved comments from the preliminary WG review. | Phil Jamieson |
| 004      | February 15 <sup>th</sup> , 2017 | Resolved CCB 2284.   | Phil Jamieson |
| 005      | July 3 <sup>rd</sup> , 2017      | Resolved errata ballot comments.                                     | Phil Jamieson |

39

40

41

42

This page is intentionally blank

43

44

## Table of Contents

|    |       |   |    |
|----|-------|---|----|
| 45 | 1     | Introduction.....   | 9  |
| 46 | 1.1   | Conformance levels.....                                     | 9  |
| 47 | 2     | References.....   | 10 |
| 48 | 2.1   | ZigBee Alliance documents .....                             | 10 |
| 49 | 2.2   | IETF documents .....  | 10 |
| 50 | 3     | PIXIT items.....  | 11 |
| 51 | 4     | PICS .....  | 12 |
| 52 | 4.1   | Usage .....   | 12 |
| 53 | 4.2   | Server.....   | 12 |
| 54 | 4.2.1 | Attributes.....   | 12 |
| 55 | 4.2.2 | Commands received.....                                      | 13 |
| 56 | 4.3   | Client .....  | 14 |
| 57 | 4.3.1 | Attributes.....   | 14 |
| 58 | 4.3.2 | Commands generated.....                                     | 14 |
| 59 | 5     | Test specification .....                                    | 15 |
| 60 | 5.1   | Introduction .....  | 15 |
| 61 | 5.1.1 | Test case overview .....                                    | 15 |
| 62 | 5.1.2 | Testing tolerances .....                                    | 15 |
| 63 | 5.1.3 | Variable rate movements .....                               | 15 |
| 64 | 5.1.4 | Client DUTs .....   | 15 |
| 65 | 5.1.5 | Test steps manipulating attributes.....                     | 16 |
| 66 | 5.2   | Generic test cases .....                                    | 17 |
| 67 | 5.2.1 | LC-TC-01G: Global attributes .....                          | 17 |
| 68 | 5.3   | Server test cases.....                                      | 21 |
| 69 | 5.3.1 | LC-TC-01S: Attributes with server as DUT.....               | 21 |
| 70 | 5.3.2 | LC-TC-02S: Primary functionality with server as DUT.....    | 26 |
| 71 | 5.3.3 | LC-TC-03S: Secondary functionality with server as DUT.....  | 34 |
| 72 | 5.3.4 | LC-TC-04S: Scenes functionality with server as DUT .....    | 41 |
| 73 | 5.3.5 | LC-TC-05S: Reporting functionality with server as DUT ..... | 46 |
| 74 | 5.3.6 | LC-TC-06S: Startup functionality with server as DUT.....    | 53 |
| 75 | 5.3.7 | LC-TC-07S: ExecuteIfOff behavior with server as DUT.....    | 58 |
| 76 | 5.4   | Client test cases .....                                     | 65 |
| 77 | 5.4.1 | LC-TC-01C: Functionality with client as DUT .....           | 65 |
| 78 | 6     | Annex A: PICS to test case cross reference.....             | 68 |
| 79 | 6.1   | Server.....   | 68 |
| 80 | 6.2   | Client .....  | 69 |





## 1 Introduction

This document contains the PICS, test specification and PICS/test case cross reference for the ZCL *level control* cluster.

### 1.1 Conformance levels

The key words "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED" and "MAY" in this document are to be interpreted as described in [R7].

## 2 References

### 2.1 ZigBee Alliance documents

- [R1] ZigBee Cluster Library Specification, ZigBee Alliance document 07-5123.
- [R2] ZCL General Test Specification, ZigBee Alliance document 15-0xxx.
- [R3] ZCL Scenes Cluster Test Specification, ZigBee Alliance document 15-0308.
- [R4] ZCL On/Off Cluster Test Specification, ZigBee Alliance document 15-0310.
- [R5] ZCL Level Control Cluster XML PICS, ZigBee Alliance document 15-0xxx.
- [R6] ZigBee Lighting & Occupancy Device Specification, ZigBee Alliance document 15-0014.

### 2.2 IETF documents

- [R7] S. Bradner, Key words for use in RFCs to Indicate Requirement Levels, IETF RFC 2119, March 1997.

**3 PIXIT items**

| Item number    | Feature   | Support |
|----------------|---|---------|
| LC.PIXIT.MINRI | What is the minimum reporting interval for reporting attributes?          | 10      |
| LC.PIXIT.MAXRI | What is the non-zero maximum reporting interval for reporting attributes? |         |

## 4 PICS

All references are for the ZigBee Cluster Library specification [R1] unless otherwise indicated.  
An XML version of these PICS is also available in [R5].

### 4.1 Usage

| Item number | Feature   | Reference | Status | Support |
|-------------|---|-----------|--------|---------|
| LC.S        | Does the device implement the <i>level control</i> cluster as a server? | 3.10.2    | O      | Yes/    |
| LC.C        | Does the device implement the <i>level control</i> cluster as a client? | 3.10.3    | O      | /No     |

### 4.2 Server

#### 4.2.1 Attributes

| Item number          | Feature   | Reference              | Status          | Support |
|----------------------|---|------------------------|-----------------|---------|
| LC.S.A0000           | Does the device implement the <i>CurrentLevel</i> attribute?  | Table 3.52, 3.10.2.3.1 | LC.S: M         | Yes/    |
| LC.S.A0000.Scene     | Does the device implement receiving and responding to the scene cluster commands for the <i>CurrentLevel</i> attribute?                               | 3.10.2.6               | (LC.S & S.S): M | Yes/    |
| LC.S.A0000.Report.Tx | Does the device implement receiving and responding to the global report attribute commands for the <i>CurrentLevel</i> attribute and sending reports? | 3.10.2.7               | LC.S: M         | Yes/    |
| LC.S.A0001           | Does the device implement the <i>RemainingTime</i> attribute?   | Table 3.52, 3.10.2.3.2 | LC.S: O         | Yes/    |
| LC.S.A000f           | Does the device implement the <i>Options</i> attribute?   | Table 3.52, 3.10.2.3.3 | LC.S: M         | Yes/    |
| LC.S.A0010           | Does the device implement the <i>OnOffTransitionTime</i> attribute?   | Table 3.52, 3.10.2.3.4 | LC.S: O         | /No     |
| LC.S.A0011           | Does the device implement the <i>OnLevel</i> attribute?   | Table 3.52, 3.10.2.3.5 | LC.S: O         | /No     |
| LC.S.A0012           | Does the device implement the <i>OnTransitionTime</i> attribute?  | Table 3.52, 3.10.2.3.6 | LC.S: O         | /No     |
| LC.S.A0013           | Does the device implement the <i>OffTransitionTime</i> attribute?   | Table 3.52, 3.10.2.3.7 | LC.S: O         | /No     |

| Item number | Feature   | Reference                 | Status  | Support |
|-------------|---|---------------------------|---------|---------|
| LC.S.A0014  | Does the device implement the <i>DefaultMoveRate</i> attribute?                 | Table 3.52, 3.10.2.3.8    | LC.S: O | /No     |
| LC.S.A4000  | Does the device implement the <i>StartUpCurrentLevel</i> attribute?             | [R6] Table 72, 27.4.1.1.1 | LC.S: O | Yes/    |
| LC.S.Afffd  | Does the device implement the <i>ClusterRevision</i> global attribute?          | Table 2-1, 2.3.5.1.1      | LC.S: M | Yes/    |
| LC.S.Afffe  | Does the device implement the <i>AttributeReportingStatus</i> global attribute? | Table 2-1, 2.3.5.1.2      | LC.S: O | /No     |

111

## 112 4.2.2 Commands received

| Item number  | Feature   | Reference              | Status  | Support |
|--------------|---|------------------------|---------|---------|
| LC.S.C00.Rsp | Does the device implement receiving the <i>Move to level</i> command?               | Table 3.53, 3.10.2.4.1 | LC.S: M | Yes/    |
| LC.S.C01.Rsp | Does the device implement receiving the <i>Move</i> command?                        | Table 3.53, 3.10.2.4.2 | LC.S: M | Yes/    |
| LC.S.C02.Rsp | Does the device implement receiving the <i>Step</i> command?                        | Table 3.53, 3.10.2.4.3 | LC.S: M | Yes/    |
| LC.S.C03.Rsp | Does the device implement receiving the <i>Stop</i> command?                        | Table 3.53, 3.10.2.4.4 | LC.S: M | Yes/    |
| LC.S.C04.Rsp | Does the device implement receiving the <i>Move to level (with on/off)</i> command? | Table 3.53, 3.10.2.4.5 | LC.S: M | Yes/    |
| LC.S.C05.Rsp | Does the device implement receiving the <i>Move (with on/off)</i> command?          | Table 3.53, 3.10.2.4.5 | LC.S: M | Yes/    |
| LC.S.C06.Rsp | Does the device implement receiving the <i>Step (with on/off)</i> command?          | Table 3.53, 3.10.2.4.5 | LC.S: M | Yes/    |
| LC.S.C07.Rsp | Does the device implement receiving the <i>Stop</i> command?                        | Table 3.53, 3.10.2.4.5 | LC.S: M | Yes/    |

113

## 4.3 Client

### 4.3.1 Attributes

| Item number           | Feature   | Reference            | Status  | Support |
|-----------------------|---|----------------------|---------|---------|
| LC.C.A0000.Report.Rsp | Does the device implement sending global report attribute command requests and receiving reports for the <i>CurrentLevel</i> attribute? | 3.10.2.7             | LC.C: O | /No     |
| LC.C.Afffd            | Does the device implement the <i>ClusterRevision</i> global attribute?  | Table 2-1, 2.3.5.1.1 | LC.C: M | /No     |
| LC.C.Afffe            | Does the device implement the <i>AttributeReportingStatus</i> global attribute?   | Table 2-1, 2.3.5.1.2 | LC.C: O | /No     |

### 4.3.2 Commands generated

| Item number | Feature   | Reference              | Status  | Support |
|-------------|---|------------------------|---------|---------|
| LC.C.C00.Tx | Does the device implement sending the <i>Move to level</i> command?               | Table 3.53, 3.10.2.4.1 | LC.C: O | /No     |
| LC.C.C01.Tx | Does the device implement sending the <i>Move</i> command?                        | Table 3.53, 3.10.2.4.2 | LC.C: O | /No     |
| LC.C.C02.Tx | Does the device implement sending the <i>Step</i> command?                        | Table 3.53, 3.10.2.4.3 | LC.C: O | /No     |
| LC.C.C03.Tx | Does the device implement sending the <i>Stop</i> command?                        | Table 3.53, 3.10.2.4.4 | LC.C: O | /No     |
| LC.C.C04.Tx | Does the device implement sending the <i>Move to level (with on/off)</i> command? | Table 3.53, 3.10.2.4.5 | LC.C: O | /No     |
| LC.C.C05.Tx | Does the device implement sending the <i>Move (with on/off)</i> command?          | Table 3.53, 3.10.2.4.5 | LC.C: O | /No     |
| LC.C.C06.Tx | Does the device implement sending the <i>Step (with on/off)</i> command?          | Table 3.53, 3.10.2.4.5 | LC.C: O | /No     |
| LC.C.C07.Tx | Does the device implement sending the <i>Stop</i> command?                        | Table 3.53, 3.10.2.4.5 | LC.C: O | /No     |

## 5 Test specification

### 5.1 Introduction

#### 5.1.1 Test case overview

The following test cases are available for the *level control* cluster:

| Test ID                  | Description                                | Reference |
|--------------------------|--|-----------|
| <b>Global tests</b>      |  |           |
| LC-TC-01G                | Global attributes                          | 5.2.1     |
| <b>Server side tests</b> |  |           |
| LC-TC-01S                | Attributes with server as DUT              | 5.3.1     |
| LC-TC-02S                | Primary functionality with server as DUT   | 5.3.2     |
| LC-TC-03S                | Secondary functionality with server as DUT | 5.3.3     |
| LC-TC-04S                | Scenes functionality with server as DUT    | 5.3.4     |
| LC-TC-05S                | Reporting functionality with server as DUT | 5.3.5     |
| LC-TC-06S                | Startup functionality with server as DUT   | 5.3.6     |
| LC-TC-07S                | ExecuteIfOff behavior with server as DUT   | 5.3.7     |
| <b>Client side tests</b> |  |           |
| LC-TC-01C                | Functionality with client as DUT           | 5.4.1     |

Unless otherwise specified, when the *Move to level*, *Step*, *Move* and *Stop* commands are used, the *OptionsMask* and *OptionsOverride* fields of SHALL NOT be included.

#### 5.1.2 Testing tolerances

In test cases where a change in an attribute value is tested over time, it is permitted for the devices involved in the test to be within a tolerance of  $\pm 15\%$  of the expected value. As such, these test cases indicate that the attribute value must be approximately equal to an expected value, to which the  $\pm 15\%$  tolerance should then be applied. All other attribute values presented are expected to be exact.

#### 5.1.3 Variable rate movements

If the device is not able to move at a variable rate then the transition time and rate fields of the move and move to level commands (and their “with On/off” equivalents) may be ignored and a fixed rate used instead.

#### 5.1.4 Client DUTs

For client test cases only test steps that pertain to commands that are supported on the DUT are required to be executed. All commands in this cluster for which support is indicated in the PICS shall be exercised, using valid, application achievable values.

140 Note that for the client attribute test case, it is permissible for the client not to be able to  
141 execute any of the test steps.

142 The client SHALL ensure that an application link, e.g. a binding link, exists between itself and  
143 the test harness. This should be configured before starting the test.

#### 144 **5.1.5 Test steps manipulating attributes**

145 In test case steps that require more than one attribute to be manipulated (e.g. read), the tester  
146 may decide whether it is appropriate or practical to send a single attribute manipulation  
147 command, containing multiple attributes, or multiple attribute manipulation commands, each  
148 containing a single attribute. The test case is designed to verify the behavior of the device  
149 supporting the attribute rather than verifying the attribute manipulation command in question.

150



## 5.2 Generic test cases

### 5.2.1 LC-TC-01G: Global attributes

This test case verifies the behavior of the global attributes of the *level control* cluster client and server.

In this test, the PICS notation LC.S.Agm and LC.C.Agm represents the list of global attributes that are specified as being mandatory for either the server or client, respectively. Similarly, the PICS notation LC.S.Ago and LC.C.Ago represents the list of global attributes that are specified as being optional for either the server or client, respectively.

#### 5.2.1.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)



*Level control* cluster (0x0008):

- All global attributes

PICS:


- LC.S, LC.C
- LC.S.Agm, LC.C.Agm, LC.S.Ago, LC.C.Ago

#### 5.2.1.2 Required devices

| Designation | Symbol  | Description  |
|-------------|---|--|
| DUT         |  | Device under test implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster server or client.</li> </ul>   |
| TH          |  | Test harness implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster client or server, i.e. the opposite cluster instantiation as implemented on the DUT.</li> </ul> |

#### 5.2.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

174 **5.2.1.4 Test preparation**

175

| LC-TC-01G: Global attributes |                                      |  |
|------------------------------|--------------------------------------|--|
| Item                         | Preparation Step                     | Observation  |
| P1                           | Form a ZigBee network.               | Observe appropriate command frame to form the network.   |
| P2                           | Power on TH and DUT.                 | TH and DUT are powered on.   |
| P3                           | Join TH and DUT to a ZigBee network. | Observe appropriate communication between TH, DUT and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-01G preparation ---

176

177 **5.2.1.5 Test procedure**

| LC-TC-01G: Global attributes |                       |  |   |
|------------------------------|-----------------------|--|---|
| Item                         | PICS                  | Test Harness Step  | DUT pass Verification   |
| 1                            | LC.S.Agm,<br>LC.C.Agm | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read each mandatory global attribute of this cluster one at a time.                                   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing each requested attribute.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).  |
| 2a                           | LC.S.Agm,<br>LC.C.Agm | TH unicasts a ZCL <i>write attributes</i> command frame to DUT to write the respective default value to each mandatory global attribute of this cluster one at a time. | DUT unicasts a ZCL <i>write attributes response</i> command frame to TH for each attribute.<br><br>If the access control of DUT is set to READ, the DUT response will indicate that the attribute write command was not a SUCCESS. If the access control of DUT is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.  |
| 2b                           | LC.S.Agm,<br>LC.C.Agm | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read back each attribute written in step 2a.  | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

Continued...

| LC-TC-01G: Global attributes |                       |   |  |
|------------------------------|-----------------------|---|--|
| Item                         | PICS                  | Test Harness Step   | DUT pass Verification  |
| 3                            | LC.S.Ago,<br>LC.C.Ago | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read each optional global attribute of this cluster one at a time.                                   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing each attribute.<br><br>If the DUT implements the attribute, the <i>Status</i> field will be equal to SUCCESS and the command will contain the requested attribute. If the DUT does not implement the attribute, the <i>Status</i> field will not be equal to SUCCESS.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s). |
| 4a                           | LC.S.Ago,<br>LC.C.Ago | TH unicasts a ZCL <i>write attributes</i> command frame to DUT to write the respective default value to each optional global attribute of this cluster one at a time. | DUT unicasts a ZCL <i>write attributes response</i> command frame to TH for each attribute.<br><br>If the attribute is not implemented or the access control of DUT is set to READ, the DUT response will indicate that the attribute write command was not a SUCCESS. If the attribute is implemented and the access control of DUT is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.  |
| 4b                           | LC.S.Ago,<br>LC.C.Ago | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read back each attribute written in step 4a.   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back.  |

--- End of test case LC-TC-01G ---

## 5.3 Server test cases

### 5.3.1 LC-TC-01S: Attributes with server as DUT

This test case verifies the behavior of the non-global attributes of the *level control* cluster server.

In this test, the PICS notation LC.S.Am represents the list of non-global attributes that are specified as being mandatory. Similarly, the PICS notation LC.S.Ao represents the list of non-global attributes that are specified as being optional.

#### 5.3.1.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)



*Level control* cluster (0x0008):

- All non-global attributes

PICS:

- LC.S
- LC.S.Am, LC.S.Ao


#### 5.3.1.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster server.</li> </ul> |

#### 5.3.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 5.3.1.4 Test preparation



| LC-TC-01S: Attributes with server as DUT |  |  |
|--|--|--|
| Item                                     | Preparation Step                                   | Observation  |
| P1                                       | Form a ZigBee network.                             | Observe appropriate command frame to form the network.   |
| P2                                       | Power on TH CLIENT and DUT SERVER.                 | TH CLIENT and DUT SERVER are powered on.   |
| P3                                       | Join TH CLIENT and DUT SERVER to a ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-01C preparation ---

205 **5.3.1.5 Test procedure**

| <b>LC-TC-01S: Attributes with server as DUT</b> |             |   |   |
|---|-------------|---|---|
| <b>Item</b>                                     | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT pass Verification</b>  |
| 1   | LC.S.Am     | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read each mandatory attribute of this cluster one at a time.                                   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing each requested attribute.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).  |
| 2a  | LC.S.Am     | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the respective default value to each mandatory attribute of this cluster one at a time. | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT for each attribute.<br><br>If the access control of DUT SERVER is set to READ, the DUT SERVER response will indicate that the attribute write command was not a SUCCESS. If the access control of DUT SERVER is set to READ/WRITE, the DUT SERVER response will indicate that the write command was a SUCCESS.                      |
| 2b  | LC.S.Am     | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read back each attribute written in step 2a.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

Continued...

| LC-TC-01S: Attributes with server as DUT |         |  |   |
|--|---------|--|---|
| Item                                     | PICS    | Test Harness Step  | DUT pass Verification   |
| 3  | LC.S.Ao | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read each optional attribute of this cluster one at a time.                                   | <p>DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing each attribute.</p> <p>If the DUT SERVER implements the attribute, the <i>Status</i> field will be equal to SUCCESS and the command will contain the requested attribute. If the DUT SERVER does not implement the attribute, the <i>Status</i> field will not be equal to SUCCESS.</p> <p>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).</p> |
| 4a                                       | LC.S.Ao | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the respective default value to each optional attribute of this cluster one at a time. | <p>DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT for each attribute.</p> <p>If the attribute is not implemented or the access control of DUT SERVER is set to READ, the DUT SERVER response will indicate that the attribute write command was not a SUCCESS. If the attribute is implemented and the access control of DUT SERVER is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.</p>   |

*Continued...*



| <b>LC-TC-01S: Attributes with server as DUT</b> |             |   |   |
|---|-------------|---|---|
| <b>Item</b>                                     | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT pass Verification</b>  |
| 4b  | LC.S.Ao     | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read back each attribute written in step 4a. | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

--- End of test case LC-TC-01S ---

206

207

### 5.3.2 LC-TC-02S: Primary functionality with server as DUT

This test case verifies the primary functionality of the *level control* cluster server.

#### 5.3.2.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Default response* command (0x0b)

*On/off* cluster (0x0006):

- *OnOff* attribute (0x0000)
- *Off* command (0x00)
- *On* command (0x01)
- *Toggle* command (0x02)



*Level control* cluster (0x0008):

- *CurrentLevel* attribute (0x0000)
- *RemainingTime* attribute (0x0001)
- *Move to level* command (0x00)
- *Step* command (0x01)
- *Move* command (0x02)
- *Stop* command (0x03)
- *Move to level (with on/off)* command (0x04)
- *Move (with on/off)* command (0x05)
- *Step (with on/off)* command (0x06)
- *Stop* command (0x07)

PICS:

- LC.S
- LC.S.A0000, LC.S.A0001
- LC.S.C00-07.Rsp
- OO.S.A0000
- OO.S.C00-02.Rsp


### 5.3.2.2 Required devices

| Designation   | Symbol  | Description  |
|---------------|---|--|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"><li>• The <i>on/off</i> cluster client and</li><li>• The <i>level control</i> cluster client.</li></ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"><li>• The <i>on/off</i> cluster server and</li><li>• The <i>level control</i> cluster server.</li></ul> |

### 5.3.2.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

### 5.3.2.4 Test preparation



| LC-TC-02S: Primary functionality with server as DUT |  |   |
|---|--|---|
| Item  | Preparation Step   | Observation   |
| P1  | Form a ZigBee network.   | Observe appropriate command frame to form the network.  |
| P2  | Power on TH CLIENT and DUT SERVER.   | TH CLIENT and DUT SERVER are powered on.  |
| P3  | Join TH CLIENT and DUT SERVER to a ZigBee network.   | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network.  |
| P4  | TH CLIENT sends an <i>off</i> command to DUT SERVER.   | If requested, DUT SERVER unicasts a <i>ZCL default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off. |
| P5  | <b><i>Conditional on DUT SERVER supporting the OnLevel attribute:</i></b><br>TH CLIENT sends a <i>write attributes</i> command to DUT SERVER to write the value of the <i>OnLevel</i> attribute to 0xff. | DUT SERVER unicasts a <i>ZCL write attributes response</i> command frame to TH CLIENT with a status of 0x00 (SUCCESS).  |

--- End of test case LC-TC-02S preparation ---

247 **5.3.2.5 Test procedure**

| <b>LC-TC-02S: Primary functionality with server as DUT</b> |              |   |  |
|--|--------------|---|--|
| <b>Item</b>  | <b>PICS</b>  | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>   |
| 0  | LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command to DUT SERVER, with the <i>level</i> field set to 0x80 and the <i>transition time</i> field set to 0x0000 (move immediately). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on and moves to its level to the mid-point. |
| 1  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.   |
| 2a   | LC.S.C05.Rsp | TH CLIENT unicasts a ZCL <i>move (with on/off)</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x00 (move up) and the <i>rate</i> field set to 0x20 (32 units per second).      | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER increases to its maximum level over 4 seconds.    |
| 2b   | LC.S.A0000   | After 6s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0xfe.   |
| 3a   | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0x80 and the <i>transition time</i> field set to 0x0000 (move immediately).               | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER immediately reduces its level to its mid-point.   |
| 3b   | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.   |

Continued...

| LC-TC-02S: Primary functionality with server as DUT |              |   |  |
|---|--------------|---|--|
| Item  | PICS         | Test Harness Step   | DUT Pass Verification  |
| 4a  | OO.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>off</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off.                              |
| 4b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.   |
| 5a  | OO.S.C01.Rsp | TH CLIENT unicasts a ZCL <i>on</i> command to DUT SERVER.   | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on.                               |
| 5b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.   |
| 6a  | LC.S.C02.Rsp | TH CLIENT unicasts a ZCL <i>step</i> command to DUT SERVER, with the <i>step mode</i> field set to 0x01 (step down), the <i>step size</i> field set to 0x40 (64 units) and the <i>transition time</i> field set to 0x0014 (2s).           | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER reduces its level.                      |
| 6b  | LC.S.C02.Rsp | After 2s, TH CLIENT unicasts a ZCL <i>step</i> command to DUT SERVER, with the <i>step mode</i> field set to 0x01 (step down), the <i>step size</i> field set to 0x40 (64 units) and the <i>transition time</i> field set to 0x0014 (2s). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER reduces its level to its minimum level. |

*Continued...*

| <b>LC-TC-02S: Primary functionality with server as DUT</b> |                        |  |  |
|--|------------------------|--|--|
| <b>Item</b>  | <b>PICS</b>            | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>   |
| 6c   | LC.S.A0000             | After 2s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x01.   |
| 7a   | OO.S.C02.Rsp           | TH CLIENT unicasts a ZCL <i>toggle</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off.                    |
| 7b   | LC.S.A0000, OO.S.A0000 | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> and <i>OnOff</i> attributes.                                       | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x01. <i>OnOff</i> attribute has the value 0x00.        |
| 8a   | OO.S.C02.Rsp           | TH CLIENT unicasts a ZCL <i>toggle</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on.                     |
| 8b   | LC.S.A0000, OO.S.A0000 | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> and <i>OnOff</i> attributes.                                       | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x01. <i>OnOff</i> attribute has the value 0x01.        |
| 9a   | LC.S.C01.Rsp           | TH CLIENT unicasts a ZCL <i>move</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x00 (move up) and the <i>rate</i> field set to 0x0a (10 units per second). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER begins to increase its level. |

Continued...

| LC-TC-02S: Primary functionality with server as DUT |              |  |  |
|---|--------------|--|--|
| Item  | PICS         | Test Harness Step  | DUT Pass Verification  |
| 9b  | LC.S.C03.Rsp | After 10s, TH CLIENT unicasts a ZCL <i>stop</i> [0x03] command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER stops adjusting its level.                |
| 9c  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x65.   |
| 10a   | LC.S.C01.Rsp | TH CLIENT unicasts a ZCL <i>move</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x01 (move down) and the <i>rate</i> field set to 0x04 (4 units per second).      | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER begins to decrease its level.             |
| 10b   | LC.S.C07.Rsp | After 10s, TH CLIENT unicasts a ZCL <i>stop</i> [0x07] command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER stops adjusting its level.                |
| 10c   | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x3d.   |
| 11a   | LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command to DUT SERVER, with the <i>level</i> field set to 0x00 and the <i>transition time</i> field set to 0x0258 (60s). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER immediately begins to decrease its level. |

Continued...



| <b>LC-TC-02S: Primary functionality with server as DUT</b> |                        |  |  |
|--|------------------------|--|--|
| <b>Item</b>  | <b>PICS</b>            | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>   |
| 11b  | LC.S.A0001             | After 10s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>RemainingTime</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>RemainingTime</i> attribute has a value approximately equal to 0x01f4.<br>DUT SERVER continues to decrease its level to its minimum level and turns off. |
| 11c  | LC.S.A0000, OO.S.A0000 | After 60s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> and <i>OnOff</i> attributes.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x01. <i>OnOff</i> attribute has the value 0x00.  |
| 12a  | LC.S.C06.Rsp           | TH CLIENT unicasts a ZCL <i>step (with on/off)</i> command to DUT SERVER, with the <i>step mode</i> field set to 0x00 (step up), the <i>step size</i> field set to 0x01 (1 unit) and the <i>transition time</i> field set to 0xffff (as fast as possible). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on at its minimum level.  |
| 12b  | LC.S.A0000, OO.S.A0000 | After 60s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> and <i>OnOff</i> attributes.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x02. <i>OnOff</i> attribute has the value 0x01.  |

--- End of test case LC-TC-02S ---

248  
249

### 5.3.3 LC-TC-03S: Secondary functionality with server as DUT

This test case verifies the secondary functionality of the *level control* cluster server.

#### 5.3.3.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)
- *Default response* command (0x0b)

*On/off* cluster (0x0006):

- *Off* command (0x00)
- *On* command (0x01)



*Level control* cluster (0x0008):

- *OnOffTransitionTime* attribute (0x0010)
- *OnLevel* attribute (0x0011)
- *OnTransitionTime* attribute (0x0012)
- *OffTransitionTime* attribute (0x0013)
- *DefaultMoveRate* attribute (0x0014)
- *Move (with on/off)* command (0x05)

PICS:

- LC.S
- LC.S.A0010-0014
- LC.S.C05.Rsp
- OO.S.C00-01.Rsp


#### 5.3.3.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>on/off</i> cluster client and</li> <li>• The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>on/off</i> cluster server and</li> <li>• The <i>level control</i> cluster server.</li> </ul> |

### 5.3.3.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

### 5.3.3.4 Test preparation



| LC-TC-03S: Secondary functionality with server as DUT |  |  |
|---|--|--|
| Item  | Preparation Step                                   | Observation  |
| P1  | Form a ZigBee network.                             | Observe appropriate command frame to form the network.   |
| P2  | Power on TH CLIENT and DUT SERVER.                 | TH CLIENT and DUT SERVER are powered on.   |
| P3  | Join TH CLIENT and DUT SERVER to a ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-03C preparation ---

**5.3.3.5 Test procedure**

| <b>LC-TC-03S: Secondary functionality with server as DUT</b> |              |   |   |
|--|--------------|---|---|
| <b>Item</b>  | <b>PICS</b>  | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>  |
| 1  | OO.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>OnOff</i> cluster, <i>off</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off.           |
| 2a   | LC.S.A0011   | <b><i>Conditional on OnLevel attribute being supported on the DUT:</i></b><br>TH CLIENT unicasts a ZCL <i>write attributes</i> command to set the <i>OnLevel</i> attribute to 0xfe.   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |
| 2b   | LC.S.A0011   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>OnLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>OnLevel</i> attribute has the value 0xfe.   |
| 3a   | LC.S.A0010   | <b><i>Conditional on the OnOffTransitionTime attribute being supported on the DUT:</i></b><br>TH CLIENT unicasts a ZCL <i>write attributes</i> command to set the <i>OnOffTransitionTime</i> attribute to 0x003c (6 seconds). | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |
| 3b   | LC.S.A0010   | <b><i>Conditional on the OnOffTransitionTime attribute being supported on the DUT:</i></b><br>TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>OnOffTransitionTime</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT with a <i>Status</i> of SUCCESS.<br><i>OnOffTransitionTime</i> attribute has the value 0x003c. |
| 3c   | LC.S.A0012   | <b><i>Conditional on the OnTransitionTime attribute being supported on the DUT:</i></b><br>TH CLIENT unicasts a ZCL <i>write attributes</i> command to set the <i>OnTransitionTime</i> attribute to 0x001e (3 seconds).       | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |

*Continued...*

| LC-TC-03S: Secondary functionality with server as DUT |              |  |  |
|---|--------------|--|--|
| Item  | PICS         | Test Harness Step  | DUT Pass Verification  |
| 3d  | LC.S.A0012   | <p><b>Conditional on the <i>OnTransitionTime</i> attribute being supported on the DUT:</b></p> <p>TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>OnTransitionTime</i> attribute.</p>     | <p>DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT with a <i>Status</i> of SUCCESS.</p> <p><i>OnTransitionTime</i> attribute has the value 0x001e.</p>  |
| 3e  | LC.S.A0013   | <p><b>Conditional on the <i>OffTransitionTime</i> attribute being supported on the DUT:</b></p> <p>TH CLIENT unicasts a ZCL <i>write attributes</i> command to set the <i>OffTransitionTime</i> attribute to 0x001e (3 seconds).</p> | <p>DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.</p>  |
| 3f  | LC.S.A0013   | <p><b>Conditional on the <i>OffTransitionTime</i> attribute being supported on the DUT:</b></p> <p>TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>OffTransitionTime</i> attribute.</p>   | <p>DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT with a <i>Status</i> of SUCCESS.</p> <p><i>OffTransitionTime</i> attribute has the value 0x001e.</p>   |
| 4a  | OO.S.C01.Rsp | <p>TH CLIENT unicasts a ZCL <i>OnOff</i> cluster, <i>on</i> command to DUT SERVER.</p>   | <p>If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).</p> <p>If the <i>OnTransitionTime</i> attribute is supported, DUT SERVER turns on over 3 seconds. Otherwise, if the <i>OnOffTransitionTime</i> attribute is supported, DUT SERVER turns on over 6 seconds. Otherwise, DUT SERVER turns on immediately.</p> |

Continued...

| LC-TC-03S: Secondary functionality with server as DUT |              |  |  |
|---|--------------|--|--|
| Item  | PICS         | Test Harness Step  | DUT Pass Verification  |
| 4b  | OO.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>OnOff</i> cluster, <i>off</i> command to DUT SERVER.   | <p>If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).</p> <p>If the <i>OffTransitionTime</i> attribute is supported, DUT SERVER turns off over 3 seconds. Otherwise, if the <i>OnOffTransitionTime</i> attribute is supported, DUT SERVER turns off over 6 seconds. Otherwise, DUT SERVER turns off immediately.</p> |
| 5a  | LC.S.A0012   | <p><b><i>Conditional on the OnTransitionTime attribute being supported on the DUT:</i></b></p> <p>TH CLIENT unicasts a ZCL <i>write attributes</i> command to DUT SERVER to set the <i>OnTransitionTime</i> attribute to 0xffff.</p>   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 5b  | OO.S.C01.Rsp | TH CLIENT unicasts a ZCL <i>OnOff</i> cluster, <i>on</i> command to DUT SERVER.  | <p>If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).</p> <p>If the <i>OnOffTransitionTime</i> attribute is supported, DUT SERVER turns on over 6 seconds. Otherwise, DUT SERVER turns on immediately.</p>   |
| 6a  | LC.S.A0013   | <p><b><i>Conditional on the OffTransitionTime attribute being supported on the DUT:</i></b></p> <p>TH CLIENT unicasts a ZCL <i>write attributes</i> command to DUT SERVER to set the <i>OffTransitionTime</i> attribute to 0xffff.</p> | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |

*Continued...*

| LC-TC-03S: Secondary functionality with server as DUT |              |   |   |
|---|--------------|---|---|
| Item  | PICS         | Test Harness Step   | DUT Pass Verification   |
| 6b  | OO.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>OnOff</i> cluster, <i>off</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>If the <i>OnOffTransitionTime</i> attribute is supported, DUT SERVER turns off over 6 seconds. Otherwise, DUT SERVER turns off immediately. |
| 7a  | LC.S.A0014   | <b>Conditional on <i>DefaultMoveRate</i> attribute being supported on the DUT:</b><br>TH CLIENT unicasts a ZCL <i>write attributes</i> command to set the <i>DefaultMoveRate</i> attribute to 0xff. | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |
| 7b  | LC.S.A0014   | <b>Conditional on <i>DefaultMoveRate</i> attribute being supported on the DUT:</b><br>TH CLIENT sends a <i>read attributes</i> command to DUT SERVER to read the <i>DefaultMoveRate</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT. <i>DefaultMoveRate</i> attribute has the value 0xff.  |
| 8a  | LC.S.C05.Rsp | TH CLIENT unicasts a ZCL <i>move (with on/off)</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x00 (move up) and the <i>rate</i> field set to 0xff (move as fast as it is able). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on and moves to its maximum level as fast as it is able.   |
| 8b  | LC.S.C05.Rsp | TH CLIENT unicasts a ZCL <i>move (with on/off)</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x01 (move down) and the <i>rate</i> field set to 0x1e (30 units per second).      | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off over 9 seconds.  |

Continued...



| LC-TC-03S: Secondary functionality with server as DUT |              |   |  |
|---|--------------|---|--|
| Item  | PICS         | Test Harness Step   | DUT Pass Verification  |
| 9a  | LC.S.A0014   | <p><b>Conditional on <i>DefaultMoveRate</i> attribute being supported on the DUT:</b></p> <p>TH CLIENT unicasts a ZCL <i>write attributes</i> command to DUT SERVER, to set the <i>DefaultMoveRate</i> attribute to the value 0x3c (60 units per second).</p> | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 9b  | LC.S.A0014   | <p><b>Conditional on <i>DefaultMoveRate</i> attribute being supported on the DUT:</b></p> <p>TH CLIENT unicasts a ZCL <i>read attributes</i> command frame for the <i>DefaultMoveRate</i> attribute to DUT SERVER.</p>  | <p>DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.</p> <p><i>DefaultMoveRate</i> attribute has the value 0x3c.</p>   |
| 10a   | LC.S.C05.Rsp | TH CLIENT unicasts a ZCL <i>move (with on/off)</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x00 (move up) and the <i>rate</i> field set to 0xff (as fast as it is able).  | <p>If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).</p> <p>If the <i>DefaultMoveRate</i> attribute is supported, DUT SERVER turns on and moves to its maximum level over 5 seconds. Otherwise, DUT SERVER turns on and moves to its maximum level as fast as it is able.</p> |
| 10b   | LC.S.C05.Rsp | TH CLIENT unicasts a ZCL <i>move (with on/off)</i> command to DUT SERVER, with the <i>move mode</i> field set to 0x01 (move down) and the <i>rate</i> field set to 0x64 (100 units per second).   | <p>If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).</p> <p>DUT SERVER turns off over 3 seconds.</p>  |

--- End of test case LC-TC-03S ---

284

285



### 5.3.4 LC-TC-04S: Scenes functionality with server as DUT

This test case verifies the scenes functionality of the *level control* cluster server.

#### 5.3.4.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Default response* command (0x0b)

*Groups* cluster (0x0004):

- *Add group* command (0x00)
- *Add group response* command (0x00)
- *Get group membership* command (0x02)
- *Get group membership response* command (0x02)
- *Remove all groups* command (0x04)

*Scenes* cluster (0x0005):

- *Remove all scenes* command (0x03)
- *Remove all scenes response* command (0x03)
- *Store scene* command (0x04)
- *Store scene response* command (0x04)
- *Recall scene* command (0x05)



*Level control* cluster (0x0008):

- *CurrentLevel* attribute (0x0000)
- *Move to level (with on/off)* command (0x04)

PICS:

- G.S, S.S, CC.S
- G.S.C00.Rsp, G.S.C02.Rsp-G.S.C04.Rsp
- G.S.C00.Tx, G.S.C02.Tx, G.S.C03.Tx
- S.S.C04.Rsp, S.S.C05.Rsp
- S.S.C04.Tx
- LC.S.A0000, LC.S.A0000.Scenes
- LC.S.C04.Rsp


#### 5.3.4.2 Required devices

| Designation   | Symbol  | Description  |
|---------------|---|--|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>groups</i> cluster client,</li> <li>• The <i>scenes</i> cluster client and</li> <li>• The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>groups</i> cluster server,</li> <li>• The <i>scenes</i> cluster server and</li> <li>• The <i>level control</i> cluster server.</li> </ul> |

#### 5.3.4.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 5.3.4.4 Test preparation



| LC-TC-04S: Scenes functionality with server as DUT |  |  |
|--|--|--|
| Item   | Preparation Step                                   | Observation  |
| P1   | Form a ZigBee network.                             | Observe appropriate command frame to form the network.   |
| P2   | Power on TH CLIENT and DUT SERVER.                 | TH CLIENT and DUT SERVER are powered on.   |
| P3   | Join TH CLIENT and DUT SERVER to a ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-04S preparation ---

325 **5.3.4.5 Test procedure**

| <b>LC-TC-04S: Scene functionality with server as DUT</b> |                             |   |  |
|--|-----------------------------|---|--|
| <b>Item</b>  | <b>PICS</b>                 | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>   |
| 1a   | G.S.C04.Rsp                 | TH CLIENT unicasts a ZCL <i>remove all groups</i> command frame to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).   |
| 1b   | G.S.C02.Rsp,<br>G.S.C02.Tx  | TH CLIENT unicasts a ZCL <i>get group membership</i> command frame to DUT SERVER with the <i>group count</i> field set to 0x00.   | DUT SERVER unicasts a ZCL <i>get group membership response</i> command frame with the <i>group count</i> field equal to 0x00.  |
| 1c   | G.S.C00.Rsp,<br>G.S.C00.Tx  | TH CLIENT unicasts ZCL <i>add group</i> command to DUT SERVER, with the <i>group ID</i> field set to 0x0001.  | DUT SERVER unicasts a ZCL <i>add group response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS) and the <i>group ID</i> field equal to 0x0001.   |
| 2  | S.S.C03.Rsp,<br>S.S.C03.Tx  | TH CLIENT unicasts a ZCL <i>remove all scenes</i> command frame to DUT SERVER with the <i>group ID</i> field set to 0x0001.   | DUT SERVER unicasts a ZCL <i>remove all scenes response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS) and the <i>group ID</i> field equal to 0x0001.                                       |
| 3a   | LC.S.A0000,<br>LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command frame to DUT SERVER with the <i>Level</i> field set to 0x7f and the <i>transition time</i> field set to 0x0000. | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br><br>DUT SERVER turns on if necessary and changes its level to the mid-point. |
| 3b   | S.S.C04.Rsp,<br>S.S.C04.Tx  | TH CLIENT unicasts a ZCL <i>store scene</i> command frame to DUT SERVER with the <i>group ID</i> field set to 0x0001 and the <i>scene ID</i> field set to 0x01.                     | DUT SERVER unicasts a ZCL <i>store scene response</i> command frame to TH CLIENT with the <i>status</i> field set to 0x00 (SUCCESS), the <i>group ID</i> field set to 0x0000 and the <i>scene ID</i> field set to 0x01.          |

Continued...

| LC-TC-04S: Scene functionality with server as DUT |                             |   |  |
|---|-----------------------------|---|--|
| Item  | PICS                        | Test Harness Step   | DUT Pass Verification  |
| 3c  | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame for the <i>CurrentLevel</i> attribute to DUT SERVER.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br>The <i>CurrentLevel</i> attribute is set to 0x7f.   |
| 3d  | LC.S.A0000,<br>LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command frame to DUT SERVER with the <i>Level</i> field set to 0xfe and the <i>transition time</i> field set to 0x0000. | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER changes the maximum value.        |
| 3e  | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame for the <i>CurrentLevel</i> attribute to DUT SERVER.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br>Verify that the values of the <i>CurrentLevel</i> attribute are different to those returned in step 3c. |
| 3f  | S.S.C05.Rsp                 | TH CLIENT unicasts a ZCL <i>recall scene</i> command frame to DUT SERVER with the <i>group ID</i> field set to 0x0001 and the <i>scene ID</i> field set to 0x01.      | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER changes to the mid-point.         |
| 3g  | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame for the <i>CurrentLevel</i> attribute to DUT SERVER.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br>Verify that the values of the <i>CurrentLevel</i> attribute are the same as were returned in step 3c.   |

--- End of test case LC-TC-04S ---

326  
327  
328

### 5.3.5 LC-TC-05S: Reporting functionality with server as DUT

This case test verifies the attribute reporting behavior of the *level control* cluster server.

#### 5.3.5.1 Scope

General:

- *Configure reporting* command (0x06)
- *Configure reporting response* command (0x07)
- *Report attributes* command (0x0a)
- *Default response* command (0x0b)

*Level control* cluster (0x0008):

- *CurrentLevel* attribute (0x0000)
- *Move to level* command (0x00)



PIXIT:

- LC.PIXIT.MINRI, LC.PIXIT.MAXRI

PICS:

- LC.S
- LC.S.A0000
- LC.S.A0000.Report.Tx
- LC.S.C00.Rsp


#### 5.3.5.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster server.</li> </ul> |

#### 5.3.5.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 5.3.5.4 Test preparation



| LC-TC-05S: Reporting functionality with server as DUT |   |  |
|---|---|--|
| Item  | Preparation Step  | Observation  |
| P1  | Form a ZigBee network.  | Observe appropriate command frame to form the network.   |
| P2  | Power on TH CLIENT and DUT SERVER.  | TH CLIENT and DUT SERVER are powered on.   |
| P3  | Join TH CLIENT and DUT SERVER to a ZigBee network.  | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |
| P5  | Establish a binding link in the reverse direction from an endpoint on DUT SERVER to a corresponding endpoint on TH CLIENT that both support the <i>level control</i> cluster. | Observe appropriate communication between DUT SERVER, TH CLIENT and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-05S preparation ---

357 **5.3.5.5 Test procedure**

| <b>LC-TC-05S: Reporting functionality with server as DUT</b> |                                  |   |  |
|--|----------------------------------|---|--|
| <b>Item</b>  | <b>PICS</b>                      | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>   |
| 0a   | LC.S.C04.Rsp                     | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command to DUT SERVER, with the <i>level</i> field set to 0x80 and the <i>transition time</i> field set to 0x0000 (move immediately). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER moves to its level to the mid-point.  |
| 0b   | LC.S.A0000                       | TH CLIENT unicasts a ZCL <i>read reporting configuration</i> command frame to DUT SERVER to read the default reporting configuration of the <i>CurrentLevel</i> attribute.                        | DUT SERVER unicasts a ZCL <i>read reporting configuration response</i> command frame to TH CLIENT with a single attribute reporting configuration record for the <i>CurrentLevel</i> attribute and the <i>status</i> field set to SUCCESS.<br><br>Set $RI_{max}$ to the value of the <i>maximum reporting interval</i> field. $RI_{max}$ is set to either 0x0000 or a value in the range 0x003d to 0xfffe.<br>Store the default report parameters contained in the <i>read reporting configuration response</i> command frame. |
| 0c   | LC.S.A0000, LC.S.A0000.Report.Tx | Wait for the attribute report according to the default configuration.   | At a time $\leq (RI_{max} + 2)$ seconds, DUT SERVER unicasts a ZCL <i>report attributes</i> command frame to TH CLIENT with the <i>CurrentLevel</i> attribute.   |

Continued...



| LC-TC-05S: Reporting functionality with server as DUT |   |  |   |
|---|---|--|---|
| Item  | PICS                                    | Test Harness Step  | DUT Pass Verification   |
| 1a  | LC.S.A0000,<br>LC.S.A0000.R<br>eport.Tx | TH CLIENT unicasts a ZCL <i>configure reporting</i> command to DUT SERVER for the <i>CurrentLevel</i> attribute with a <i>direction</i> field set to 0x00, the <i>minimum reporting interval</i> field set to LC.PIXIT.MINRI, the <i>maximum reporting interval</i> field set to LC.PIXIT.MAXRI and the <i>reportable change</i> field set equal to or less than 25% of the device's valid value range (if valid range is between 0 – 100 with a resolution of 1, set the <i>reportable change</i> field to 0x0a (10%)). | DUT SERVER unicasts a ZCL <i>configure reporting response</i> command to TH CLIENT, confirming the configured attribute and with the <i>status</i> field set to SUCCESS.                            |
| 1b  | LC.S.A0000,<br>LC.S.A0000.R<br>eport.Tx | None   | At a time $\leq$ (LC.PIXIT.MAXRI + 2) seconds after step 1a, DUT SERVER unicasts a ZCL <i>report attributes</i> command to TH CLIENT with the <i>CurrentLevel</i> attribute.                        |
| 2a  | LC.S.C00.Rsp                            | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER with the <i>level</i> field set to a value such that the <i>CurrentLevel</i> attribute is changed by a value less than the <i>reportable change</i> field (from the <i>configure reporting</i> command) and the <i>transition time</i> field set to 0x0000.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER increases its level accordingly.     |
| 2c  | LC.S.A0000,<br>LC.S.A0000.R<br>eport.Tx | None   | At a time approximately LC.PIXIT.MAXRI seconds after sending the report in step 1b, DUT SERVER unicasts a ZCL <i>report attributes</i> command to TH CLIENT with the <i>CurrentLevel</i> attribute. |

Continued...

| LC-TC-05S: Reporting functionality with server as DUT |                                      |  |   |
|---|--------------------------------------|--|---|
| Item  | PICS                                 | Test Harness Step  | DUT Pass Verification   |
| 3a  | LC.S.C00.Rsp                         | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER with the <i>level</i> field set to a value such that the <i>CurrentLevel</i> attribute is changed by a value equal to or greater than the <i>reportable change</i> field (from the <i>configure reporting</i> command) and the <i>transition time</i> field set to 0x0000. | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER decreases its level accordingly.     |
| 3b  | LC.S.A0000, LC.S.A0000.R<br>eport.Tx | None   | At a time approximately LC.PIXIT.MINRI seconds after sending the report in step 2c, DUT SERVER unicasts a ZCL <i>report attributes</i> command to TH CLIENT with the <i>CurrentLevel</i> attribute. |
| 3c  | LC.S.A0000, LC.S.A0000.R<br>eport.Tx | None   | At a time approximately LC.PIXIT.MAXRI seconds after sending the report in step 3b, DUT SERVER unicasts a ZCL <i>report attributes</i> command to TH CLIENT with the <i>CurrentLevel</i> attribute. |
| 4a  | LC.S.A0000, LC.S.A0000.R<br>eport.Tx | TH CLIENT unicasts a ZCL <i>configure reporting</i> command to DUT SERVER for the <i>CurrentLevel</i> attribute the <i>maximum reporting interval</i> field set to 0xffff (do not send reports).   | DUT SERVER unicasts a ZCL <i>configure reporting response</i> command to TH CLIENT, confirming the configured attribute and with the <i>status</i> field set to SUCCESS.                            |
| 4b  | LC.S.A0000.R<br>eport.Tx             | Wait for (LC.PIXIT.MAXRI + 2) seconds after the report sent in step 3c.  | DUT SERVER does not send any further reports.   |

| LC-TC-05S: Reporting functionality with server as DUT |            |  |   |
|---|------------|--|---|
| Item  | PICS       | Test Harness Step  | DUT Pass Verification   |
| 5   | LC.S.A0000 | TH CLIENT unicasts a ZCL <i>read reporting configuration</i> command frame to DUT SERVER to read the default reporting configuration of the <i>CurrentLevel</i> attribute. | DUT SERVER unicasts a ZCL <i>read reporting configuration response</i> command frame to TH CLIENT with a single attribute reporting configuration record for the <i>CurrentLevel</i> attribute and the <i>status</i> field equal to either 0x8b (NOT_FOUND) or 0x00 (SUCCESS). If the <i>status</i> field is equal to 0x00, the <i>maximum reporting interval</i> field is equal to 0xffff. |

Continued...

|    |                                  |  |  |
|----|----------------------------------|--|--|
| 6a | LC.S.A0000                       | TH CLIENT unicasts a ZCL <i>configure reporting</i> command frame to DUT SERVER for the <i>CurrentLevel</i> attribute with a <i>direction</i> field set to 0x00, the <i>minimum reporting interval</i> field set to 0xffff and the <i>maximum reporting interval</i> field set to 0x0000 (restore default report configuration). | DUT SERVER unicasts a ZCL <i>configure reporting response</i> command frame to TH CLIENT, confirming the configured attributes and with the <i>status</i> field set to SUCCESS.  |
| 6b | LC.S.A0000                       | TH CLIENT unicasts a ZCL <i>read reporting configuration</i> command frame to DUT SERVER to read the default reporting configuration of the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read reporting configuration response</i> command frame to TH CLIENT with a single attribute reporting configuration record for the <i>CurrentLevel</i> attribute and the <i>status</i> field set to SUCCESS.<br><br>Verify that the default reporting configuration is commensurate with the parameters stored in step 0b. |
| 6c | LC.S.A0000, LC.S.A0000.Report.Tx | Wait for the attribute report according to the default configuration.  | At a time $\leq (RI_{max} + 2)$ seconds, DUT SERVER unicasts a ZCL <i>report attributes</i> command frame to TH CLIENT with the <i>CurrentLevel</i> attribute.   |

--- End of test case LC-TC-05S ---

359

### 5.3.6 LC-TC-06S: Startup functionality with server as DUT

This case test verifies the startup functionality of the *level control* cluster server.

#### 5.3.6.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)
- *Default response* command (0x0b)

*On/off* cluster (0x0006):

- *StartUpOnOff* attribute (0x4003)



*Level control* cluster (0x0008):

- *CurrentLevel* attribute (0x0000)
- *StartUpCurrentLevel* attribute (0x4000)
- *Move to level (with on/off)* command (0x04)

PICS:

- LC.S
- LC.S.A0000, LC.S.A4000
- LC.S.C04.Rsp


#### 5.3.6.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>on/off</i> cluster client and</li> <li>• The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>on/off</i> cluster server and</li> <li>• The <i>level control</i> cluster server.</li> </ul> |

**5.3.6.3 Initial conditions**

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 5.3.6.4 Test preparation



| LC-TC-06S: Startup functionality with server as DUT |  |  |
|---|--|--|
| Item  | Preparation Step                                   | Observation  |
| P1  | Form a ZigBee network.                             | Observe appropriate command frame to form the network.   |
| P2  | Power on TH CLIENT and DUT SERVER.                 | TH CLIENT and DUT SERVER are powered on.   |
| P3  | Join TH CLIENT and DUT SERVER to a ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-06S preparation ---

389 **5.3.6.5 Test procedure**

| <b>LC-TC-06S: Startup functionality with server as DUT</b> |                             |  |  |
|--|-----------------------------|--|--|
| <b>Item</b>  | <b>PICS</b>                 | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>   |
| 1a   | LC.S.A0000,<br>LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command frame to DUT SERVER with the <i>Level</i> field set to 0x7f.   | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on if necessary and changes its level to the mid-point. |
| 1b   | -                           | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the value 0xff (startup in the previous state) to the <i>OnOff</i> cluster, <i>StartUpOnOff</i> attribute. | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 2a   | LC.S.A4000                  | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the value 0xfe to the <i>StartUpCurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 2b   | -                           | Power off DUT SERVER.  | None.  |
| 2c   | -                           | Power on DUT SERVER.   | DUT SERVER is powered at its maximum level.  |
| 2d   | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT. <i>CurrentLevel</i> attribute has the value 0xfe.  |
| 3a   | LC.S.A4000                  | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the value 0x01 to the <i>StartUpCurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 3b   | -                           | Power off DUT SERVER.  | None.  |
| 3c   | -                           | Power on DUT SERVER.   | DUT SERVER is powered at its minimum level.  |

*Continued...*



| <b>LC-TC-06S: Startup functionality with server as DUT</b> |                             |  |  |
|--|-----------------------------|--|--|
| <b>Item</b>  | <b>PICS</b>                 | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>   |
| 3d   | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT. <i>CurrentLevel</i> attribute has the value 0x01.  |
| 4a   | LC.S.A0000,<br>LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command frame to DUT SERVER with the <i>Level</i> field set to 0x7f.   | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns on if necessary and changes its level to the mid-point. |
| 4b   | LC.S.A4000                  | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the value 0xff (start up at the previous level) to the <i>StartUpCurrentLevel</i> attribute. | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 4c   | -                           | Power off DUT SERVER.  | None.  |
| 4d   | -                           | Power on DUT SERVER.   | DUT SERVER is powered at its mid-point level.  |
| 4e   | LC.S.A0000                  | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT. <i>CurrentLevel</i> attribute has the value 0x7f.  |

--- End of test case LC-TC-06S ---

390  
391

### 5.3.7 LC-TC-07S: ExecutelfOff behavior with server as DUT

This test case verifies the behavior of the *ExecuteIfOff* option of the *level control* cluster server.

Note: this test case only verifies the *ExecuteIfOff* behavior with the *Move to level* command and it is assumed that the *Step*, *Move* and *Stop* commands exhibit the same behavior. If preferred, the tester can either repeat the test for each command or substitute a random command in place of the *Move to level* command as written.

#### 5.3.7.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)
- *Default response* command (0x0b)

*On/off* cluster (0x0006):

- *Off* command (0x00)



*Level control* cluster (0x0008):

- *CurrentLevel* attribute (0x0000)
- *Options* attribute (0x000f)
- *Move to level* command (0x00)
- *Move to level (with on/off)* command (0x04)

PICS:

- LC.S
- LC.S.A0000, LC.S.A000f
- LC.S.C00.Rsp, LC.S.C04.Rsp
- OO.S.C00.Rsp


### 5.3.7.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>The <i>on/off</i> cluster client and</li> <li>The <i>level control</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>The <i>on/off</i> cluster server and</li> <li>The <i>level control</i> cluster server.</li> </ul> |

### 5.3.7.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 5.3.7.4 Test preparation



| LC-TC-07S: ExecutelfOff behavior with server as DUT |  |  |
|---|--|--|
| Item  | Preparation Step                                   | Observation  |
| P1  | Form a ZigBee network.                             | Observe appropriate command frame to form the network.   |
| P2  | Power on TH CLIENT and DUT SERVER.                 | TH CLIENT and DUT SERVER are powered on.   |
| P3  | Join TH CLIENT and DUT SERVER to a ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-07S preparation ---

427 **5.3.7.5 Test procedure**

| <b>LC-TC-07S: ExecuteIfOff behavior with server as DUT</b> |              |   |   |
|--|--------------|---|---|
| <b>Item</b>  | <b>PICS</b>  | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>  |
| 1a   | LC.S.C04.Rsp | TH CLIENT unicasts a ZCL <i>move to level (with on/off)</i> command to DUT SERVER, with the <i>level</i> field set to 0x80 and the <i>transition time</i> field set to 0x0000 (move immediately).   | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER moves to its level to the mid-point. |
| 1b   | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.  |
| 2  | OO.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>off</i> command to DUT SERVER.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER turns off.                           |
| 3  | OO.S.A000f   | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to set the <i>Options</i> attribute to 0x00 ( <i>ExecuteIfOff</i> bit not set).  | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |
| 4a   | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0x01, the <i>transition time</i> field set to 0x0000 (move immediately) and the <i>OptionsMask</i> and <i>OptionsOverride</i> fields omitted. | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing.                        |
| 4b   | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.  |

Continued...

| LC-TC-07S: ExecuteIfOff behavior with server as DUT |              |  |  |
|---|--------------|--|--|
| Item  | PICS         | Test Harness Step  | DUT Pass Verification  |
| 5a  | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0x01, the <i>transition time</i> field set to 0x0000 (move immediately), the <i>OptionsMask</i> field set to 0x01 and the <i>OptionsOverride</i> field set to 0x00 ( <i>ExecuteIfOff</i> bit not set). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing. |
| 5b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.                                   |
| 6a  | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0x01, the <i>transition time</i> field set to 0x0000 (move immediately), the <i>OptionsMask</i> field set to 0x01 and the <i>OptionsOverride</i> field set to 0x01 ( <i>ExecuteIfOff</i> bit set).     | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing. |
| 6b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x01.                                   |
| 7   | OO.S.A000f   | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to set the <i>Options</i> attribute to 0x01 ( <i>ExecuteIfOff</i> bit set).   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |

Continued...

| LC-TC-07S: ExecuteIfOff behavior with server as DUT |              |  |  |
|---|--------------|--|--|
| Item  | PICS         | Test Harness Step  | DUT Pass Verification  |
| 8a  | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0x80, the <i>transition time</i> field set to 0x0000 (move immediately) and the <i>OptionsMask</i> and <i>OptionsOverride</i> fields omitted.  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing. |
| 8b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.                                   |
| 9a  | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0xfe, the <i>transition time</i> field set to 0x0000 (move immediately), the <i>OptionsMask</i> field set to 0x01 and the <i>OptionsOverride</i> field set to 0x00 ( <i>ExecuteIfOff</i> bit not set). | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing. |
| 9b  | LC.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0x80.                                   |
| 10a   | LC.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>move to level</i> command to DUT SERVER, with the <i>level</i> field set to 0xfe, the <i>transition time</i> field set to 0x0000 (move immediately), the <i>OptionsMask</i> field set to 0x01 and the <i>OptionsOverride</i> field set to 0x01 ( <i>ExecuteIfOff</i> bit set).     | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER does nothing. |

Continued...

| LC-TC-07S: ExecuteIfOff behavior with server as DUT |            |  |  |
|---|------------|--|--|
| Item  | PICS       | Test Harness Step  | DUT Pass Verification  |
| 10b   | LC.S.A0000 | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>CurrentLevel</i> attribute. | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>CurrentLevel</i> attribute has the value 0xfe. |

--- End of test case LC-TC-07S ---

428



## 5.4 Client test cases

### 5.4.1 LC-TC-01C: Functionality with client as DUT

This case test verifies the functionality of the *level control* cluster client.

The DUT client SHALL be on the same network as a suitable server, provided by the user, and this device SHALL be used by the client to exercise its functionality. The test case uses the test harness to prompt the user, based on the declared PICS, to exercise the functionality of the *basic* cluster client and to verify the results. A sniffer tool SHALL be used to log the exercised functionality and to determine its validity.

In this test case, the PICS notation LC.C.CdTx represents the list of commands that are declared as being transmitted by the DUT.

#### 5.4.1.1 Scope



*Level control* cluster (0x0008):

- *Move to level* command (0x00)
- *Move* command (0x01)
- *Step* command (0x02)
- *Stop* command (0x03)
- *Move to level (with on/off)* command (0x04)
- *Move (with on/off)* command (0x05)
- *Step (with on/off)* command (0x06)
- *Stop* command (0x07)

PICS:

- LC.C
- LC.C.C00-07.Tx


#### 5.4.1.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| DUT<br>CLIENT |  | Device under test client implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster client.</li> </ul> |
| SERVER        |  | Suitable server device implementing: <ul style="list-style-type: none"> <li>• The <i>level control</i> cluster server.</li> </ul>   |

### 5.4.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

### 5.4.1.4 Test preparation



| LC-TC-01C: Functionality with client as DUT |  |   |
|---|--|---|
| Item  | Preparation Step   | Observation   |
| P1  | Power on the DUT CLIENT device and the SERVER device.                              | DUT CLIENT and SERVER are powered on.   |
| P2  | Ensure the DUT CLIENT device and the SERVER device are on the same ZigBee network. | Observe appropriate communication between DUT CLIENT, SERVER and any other relevant node on the ZigBee network. |

--- End of test case LC-TC-01C preparation ---

461 **5.4.1.5 Test procedure**

| <b>LC-TC-01C: Functionality with client as DUT</b> |             |  |   |
|--|-------------|--|---|
| <b>Item</b>  | <b>PICS</b> | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>  |
| 1  | -           | Test harness prompts the user with a list of commands, based on the declared PICS, which the DUT CLIENT indicates it can transmit. | None.   |
| 2  | LC.C.Cd.Tx  | None.  | DUT CLIENT transmits correctly formed commands in any order and with application achievable values. This is verified using the sniffer log. |
| 3  | -           | Prompt the user to verify that the cluster commands listed in step 1 were transmitted during step 2.                               | During step 2, DUT CLIENT has transmitted every command listed by the test harness in step 1.   |
| 4  | -           | Prompt the user to verify that the cluster commands not listed in step 1 were not transmitted during step 2.                       | During step 2, DUT CLIENT has not transmitted any commands from this cluster that were not listed by the test harness in step 1.            |

--- End of test case LC-TC-01C ---

462  
463

## 6 Annex A: PICS to test case cross reference

### 6.1 Server

| PICS                 | Test case |           |           |           |           |           |           |           |
|----------------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
|                      | LC-TC-01G | LC-TC-01S | LC-TC-02S | LC-TC-03S | LC-TC-04S | LC-TC-05S | LC-TC-06S | LC-TC-07S |
| LC.S                 | X         | X         | X         | X         | X         | X         | X         | X         |
| LC.S.A0000           |           | X         | X         |           | X         | X         | X         | X         |
| LC.S.A0000.Scene     |           |           |           |           | X         |           |           |           |
| LC.S.A0000.Report.Tx |           |           |           |           |           | X         |           |           |
| LC.S.A0001           |           | X         | X         |           |           |           |           |           |
| LC.S.A000f           |           | X         |           |           |           |           |           | X         |
| LC.S.A0010           |           | X         |           | X         |           |           |           |           |
| LC.S.A0011           |           | X         |           | X         |           |           |           |           |
| LC.S.A0012           |           | X         |           | X         |           |           |           |           |
| LC.S.A0013           |           | X         |           | X         |           |           |           |           |
| LC.S.A0014           |           | X         |           | X         |           |           |           |           |
| LC.S.A4000           |           | X         |           |           |           |           | X         |           |
| LC.S.Afffd           | X         |           |           |           |           |           |           |           |
| LC.S.Afffe           | X         |           |           |           |           |           |           |           |
| LC.S.C00.Rsp         |           |           | X         |           | X         | X         |           | X         |
| LC.S.C01.Rsp         |           |           | X         |           |           |           |           |           |
| LC.S.C02.Rsp         |           |           | X         |           |           |           |           |           |
| LC.S.C03.Rsp         |           |           | X         |           |           |           |           |           |
| LC.S.C04.Rsp         |           |           | X         |           |           |           | X         | X         |
| LC.S.C05.Rsp         |           |           | X         | X         |           |           |           |           |
| LC.S.C06.Rsp         |           |           | X         |           |           |           |           |           |
| LC.S.C07.Rsp         |           |           | X         |           |           |           |           |           |

468 **6.2 Client**

| PICS                  | Test case |           |
|-----------------------|-----------|-----------|
|                       | LC-TC-01G | LC-TC-01C |
| LC.C                  | X         | X         |
| LC.C.A0000.Report.Rsp |           | X         |
| LC.C.Afffd            | X         |           |
| LC.C.Affe             | X         |           |
| LC.C.C00.Tx           |           | X         |
| LC.C.C01.Tx           |           | X         |
| LC.C.C02.Tx           |           | X         |
| LC.C.C03.Tx           |           | X         |
| LC.C.C04.Tx           |           | X         |
| LC.C.C05.Tx           |           | X         |
| LC.C.C06.Tx           |           | X         |
| LC.C.C07.Tx           |           | X         |

469

470