



**ZigBee®**

Control your world

# **ZigBee Cluster Library Basic Cluster (0x0000) Test Specification Version 1.0**

ZigBee Document 15-0302-05

April 15th, 2016

Sponsored by: ZigBee Alliance

Accepted by                      This document has been accepted for release by the ZigBee Alliance Board of Directors

Abstract                          This document describes the certification tests for devices which implement the ZCL Basic cluster.

Keywords                        ZCL, Basic, cluster

---

Copyright © ZigBee Alliance, Inc. (1996-2016). All rights reserved.

508 Second Street, Suite 206 Davis, CA 95616 - USA

<http://www.zigbee.org>

Permission is granted to members of the ZigBee Alliance to reproduce this document for their own use or the use of other ZigBee Alliance members only, provided this notice is included. All other rights reserved. Duplication for sale, or for commercial or for-profit use is strictly prohibited without the prior written consent of the ZigBee Alliance.

1

2

This page is intentionally blank

## 3 Notice of use and disclosure

4 Copyright © ZigBee Alliance, Inc. (1996-2016). All rights Reserved. This  
5 information within this document is the property of the ZigBee Alliance and its use  
6 and disclosure are restricted.

7 Elements of ZigBee Alliance specifications may be subject to third party intellectual  
8 property rights, including without limitation, patent, copyright or trademark rights  
9 (such a third party may or may not be a member of ZigBee). ZigBee is not responsible  
10 and shall not be held responsible in any manner for identifying or failing to identify  
11 any or all such third party intellectual property rights.

12 No right to use any ZigBee name, logo or trademark is conferred herein. Use of any  
13 ZigBee name, logo or trademark requires membership in the ZigBee Alliance and  
14 compliance with the ZigBee Logo and Trademark Policy and related ZigBee policies.

15 This document and the information contained herein are provided on an “AS IS” basis  
16 and ZigBee DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED,  
17 INCLUDING BUT NOT LIMITED TO (A) ANY WARRANTY THAT THE USE  
18 OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OF  
19 THIRD PARTIES (INCLUDING WITHOUT LIMITATION ANY  
20 INTELLECTUAL PROPERTY RIGHTS INCLUDING PATENT, COPYRIGHT OR  
21 TRADEMARK RIGHTS) OR (B) ANY IMPLIED WARRANTIES OF  
22 MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE OR  
23 NONINFRINGEMENT. IN NO EVENT WILL ZIGBEE BE LIABLE FOR ANY  
24 LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OF DATA,  
25 INTERRUPTION OF BUSINESS, OR FOR ANY OTHER DIRECT, INDIRECT,  
26 SPECIAL OR EXEMPLARY, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL  
27 DAMAGES OF ANY KIND, IN CONTRACT OR IN TORT, IN CONNECTION  
28 WITH THIS DOCUMENT OR THE INFORMATION CONTAINED HEREIN,  
29 EVEN IF ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. All  
30 Company, brand and product names may be trademarks that are the sole property of  
31 their respective owners.

32 The above notice and this paragraph must be included on all copies of this document  
33 that are made.

34

35

36

37

This page is intentionally blank

38

## Revision history

| Revision | Date                              | Details   | Editor        |
|----------|-----------------------------------|---|---------------|
| 00       | April, 2015                       | Created from ZLL & ZHA test specifications.   | Phil Jamieson |
| 01       | August 12 <sup>th</sup> , 2015    | Resolved comments received since the Hull test event in June 2015.                      | Phil Jamieson |
| 02       | September 28 <sup>th</sup> , 2015 | Added new attributes from the L&O specification and the new mandatory global attribute. | Phil Jamieson |
| 03       | October 30 <sup>th</sup> , 2015   | Addressed comments from GTE #3 and the v0.9 ballot.                                     | Phil Jamieson |
| 04       | March 1 <sup>st</sup> , 2016      | Addressed comments from the ZigBee 3.0 SVEs.  | Phil Jamieson |
| 05       | April 15 <sup>th</sup> , 2016     | Changed status to "approved" and version to 1.0.  | Phil Jamieson |

39

40

41

42

This page is intentionally blank

43

|    |                          |   |
|----|--------------------------|---|
| 44 | <b>Table of Contents</b> |   |
| 45 | 1                        | Introduction.....9  |
| 46 | 1.1                      | Conformance levels ..... 9                                    |
| 47 | 2                        | References..... 10  |
| 48 | 2.1                      | ZigBee Alliance documents ..... 10                            |
| 49 | 2.2                      | IETF documents ..... 10                                       |
| 50 | 3                        | PICS ..... 11   |
| 51 | 3.1                      | Usage ..... 11  |
| 52 | 3.2                      | Server..... 11  |
| 53 | 3.2.1                    | Attributes..... 11  |
| 54 | 3.2.2                    | Commands received..... 12                                     |
| 55 | 3.3                      | Client ..... 12   |
| 56 | 3.3.1                    | Attributes..... 12  |
| 57 | 3.3.2                    | Commands generated..... 13                                    |
| 58 | 4                        | Test specification ..... 14                                   |
| 59 | 4.1                      | Introduction ..... 14   |
| 60 | 4.1.1                    | Test case overview ..... 14                                   |
| 61 | 4.1.2                    | Testing tolerances ..... 14                                   |
| 62 | 4.1.3                    | Client DUTs ..... 14  |
| 63 | 4.1.4                    | Test steps manipulating attributes..... 14                    |
| 64 | 4.2                      | Generic test cases ..... 15                                   |
| 65 | 4.2.1                    | B-TC-01G: Global attributes ..... 15                          |
| 66 | 4.3                      | Server test cases..... 19                                     |
| 67 | 4.3.1                    | B-TC-01S: Attributes with server as DUT ..... 19              |
| 68 | 4.3.2                    | B-TC-02S: Secondary functionality with server as DUT ..... 24 |
| 69 | 4.4                      | Client test cases ..... 29                                    |
| 70 | 4.4.1                    | B-TC-01C: Functionality with client as DUT ..... 29           |
| 71 | 5                        | Annex A: PICS to test case cross reference..... 32            |
| 72 | 5.1                      | Server..... 32  |
| 73 | 5.2                      | Client ..... 32   |
| 74 |                          |   |
| 75 |                          |   |

76

77

This page is intentionally blank



# 1 Introduction

This document contains the PICS, test specification and PICS/test case cross reference for the ZCL *basic* cluster.

## 1.1 Conformance levels

The key words "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED" and "MAY" in this document are to be interpreted as described in [R5].

## 2 References

### 2.1 ZigBee Alliance documents

- [R1] ZigBee Cluster Library Specification, ZigBee Alliance document 07-5123.
- [R2] ZCL General Test Specification, ZigBee Alliance document 15-0xxx.
- [R3] ZCL Basic Cluster XML PICS, ZigBee Alliance document 15-0xxx.
- [R4] ZigBee Lighting & Occupancy Device Specification, ZigBee Alliance document 15-0014.

### 2.2 IETF documents

- [R5] S. Bradner, Key words for use in RFCs to Indicate Requirement Levels, IETF RFC 2119, March 1997.

### 3 PICS

All references are for the ZigBee Cluster Library specification [R1] unless otherwise indicated.  
An XML version of these PICS is also available in [R3].

#### 3.1 Usage

| Item number | Feature   | Reference | Status | Support            |
|-------------|---|-----------|--------|--------------------|
| B.S         | Does the device implement the <i>basic</i> cluster as a server? | 3.2.2     | O      | Yes/ <del>No</del> |
| B.C         | Does the device implement the <i>basic</i> cluster as a client? | 3.2.3     | O      | <del>Yes</del> /No |

#### 3.2 Server

##### 3.2.1 Attributes

| Item number | Feature  | Reference                 | Status | Support            |
|-------------|--|---------------------------|--------|--------------------|
| B.S.A0000   | Does the device implement the <i>ZCLVersion</i> attribute?         | Table 3.7, 3.2.2.2.1      | B.S: M | Yes/ <del>No</del> |
| B.S.A0001   | Does the device implement the <i>ApplicationVersion</i> attribute? | Table 3.7, 3.2.2.2.2      | B.S: O | <del>Yes</del> /No |
| B.S.A0002   | Does the device implement the <i>StackVersion</i> attribute?       | Table 3.7, 3.2.2.2.3      | B.S: O | <del>Yes</del> /No |
| B.S.A0003   | Does the device implement the <i>HardwareVersion</i> attribute?    | Table 3.7, 3.2.2.2.4      | B.S: O | <del>Yes</del> /No |
| B.S.A0004   | Does the device implement the <i>ManufacturerName</i> attribute?   | Table 3.7, 3.2.2.2.5      | B.S: O | Yes/ <del>No</del> |
| B.S.A0005   | Does the device implement the <i>ModelIdentifier</i> attribute?    | Table 3.7, 3.2.2.2.6      | B.S: O | Yes/ <del>No</del> |
| B.S.A0006   | Does the device implement the <i>DateCode</i> attribute?           | Table 3.7, 3.2.2.2.7      | B.S: O | <del>Yes</del> /No |
| B.S.A0007   | Does the device implement the <i>PowerSource</i> attribute?        | Table 3.7, 3.2.2.2.8      | B.S: M | Yes/ <del>No</del> |
| B.S.A0008   | Does the device implement the <i>GenericDeviceClass</i> attribute? | [R4] Table 66, 27.2.1.1.1 | B.S: O | <del>Yes</del> /No |
| B.S.A0009   | Does the device implement the <i>GenericDeviceType</i> attribute?  | [R4] Table 66, 27.2.1.1.2 | B.S: O | <del>Yes</del> /No |

| Item number | Feature  | Reference                 | Status | Support            |
|-------------|--|---------------------------|--------|--------------------|
| B.S.A000a   | Does the device implement the <i>ProductCode</i> attribute?            | [R4] Table 66, 27.2.1.1.3 | B.S: O | <del>Yes</del> /No |
| B.S.A000b   | Does the device implement the <i>ProductURL</i> attribute?             | [R4] Table 66, 27.2.1.1.4 | B.S: O | <del>Yes</del> /No |
| B.S.A0010   | Does the device implement the <i>LocationDescription</i> attribute?    | Table 3.7, 3.2.2.2.9      | B.S: O | <del>Yes</del> /No |
| B.S.A0011   | Does the device implement the <i>PhysicalEnvironment</i> attribute?    | Table 3.7, 3.2.2.2.10     | B.S: O | <del>Yes</del> /No |
| B.S.A0012   | Does the device implement the <i>DeviceEnabled</i> attribute?          | Table 3.7, 3.2.2.2.11     | B.S: O | <del>Yes</del> /No |
| B.S.A0013   | Does the device implement the <i>AlarmMask</i> attribute?              | Table 3.7, 3.2.2.2.12     | B.S: O | <del>Yes</del> /No |
| B.S.A0014   | Does the device implement the <i>DisableLocalConfig</i> attribute?     | Table 3.7, 3.2.2.2.13     | B.S: O | <del>Yes</del> /No |
| B.S.A4000   | Does the device implement the <i>SWBuildID</i> attribute?              | Table 3.7, 3.2.2.2.14     | B.S: O | <del>Yes</del> /No |
| B.S.Afffd   | Does the device implement the <i>ClusterRevision</i> global attribute? | Table 2-1, 2.3.5.1.1      | B.S: M | Yes/ <del>No</del> |

### 3.2.2 Commands received

| Item number | Feature   | Reference             | Status | Support            |
|-------------|---|-----------------------|--------|--------------------|
| B.S.C00.Rsp | Does the device implement receiving the <i>Reset to factory defaults</i> command? | Table 3.13, 3.2.2.3.1 | B.S: O | <del>Yes</del> /No |

## 3.3 Client

### 3.3.1 Attributes

| Item number | Feature  | Reference            | Status | Support            |
|-------------|--|----------------------|--------|--------------------|
| B.C.Afffd   | Does the device implement the <i>ClusterRevision</i> global attribute? | Table 2-1, 2.3.5.1.1 | B.C: M | <del>Yes</del> /No |

109 **3.3.2 Commands generated**

| Item number | Feature   | Reference             | Status | Support            |
|-------------|---|-----------------------|--------|--------------------|
| B.C.C00.Tx  | Does the device implement sending the <i>Reset to factory defaults</i> command? | Table 3.13, 3.2.2.3.1 | B.C: O | <del>Yes</del> /No |

110

## 4 Test specification

### 4.1 Introduction

#### 4.1.1 Test case overview

The following test cases are available for the *basic* cluster:

| Test ID                  | Description                                | Reference |
|--------------------------|--|-----------|
| <b>Global tests</b>      |  |           |
| B-TC-01G                 | Global attributes                          | 4.2.1     |
| <b>Server side tests</b> |  |           |
| B-TC-01S                 | Attributes with server as DUT              | 4.3.1     |
| B-TC-02S                 | Secondary functionality with server as DUT | 4.3.2     |
| <b>Client side tests</b> |  |           |
| B-TC-02C                 | Functionality with client as DUT           | 4.4.1     |

#### 4.1.2 Testing tolerances

In test cases where a change in an attribute value is tested over time, it is permitted for the devices involved in the test to be within a tolerance of  $\pm 15\%$  of the expected value. As such, these test cases indicate that the attribute value must be approximately equal to an expected value, to which the  $\pm 15\%$  tolerance should then be applied. All other attribute values presented are expected to be exact.

#### 4.1.3 Client DUTs

For client test cases only test steps that pertain to commands that are supported on the DUT are required to be executed. All commands in this cluster for which support is indicated in the PICS shall be exercised, using valid, application achievable values.

Note that for the client attribute test case, it is permissible for the client not to be able to execute any of the test steps.

The client SHALL ensure that an application link, e.g. a binding link, exists between itself and the test harness. This should be configured before starting the test.

#### 4.1.4 Test steps manipulating attributes

In test case steps that require more than one attribute to be manipulated (e.g. read), the tester may decide whether it is appropriate or practical to send a single attribute manipulation command, containing multiple attributes, or multiple attribute manipulation commands, each containing a single attribute. The test case is designed to verify the behavior of the device supporting the attribute rather than verifying the attribute manipulation command in question.

## 4.2 Generic test cases

### 4.2.1 B-TC-01G: Global attributes

This test case verifies the behavior of the global attributes of the *basic* cluster client and server. In this test, the PICS notation B.S.Agm and B.C.Agm represents the list of global attributes that are specified as being mandatory for either the server or client, respectively. Similarly, the PICS notation B.S.Ago and B.C.Ago represents the list of global attributes that are specified as being optional for either the server or client, respectively.

#### 4.2.1.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)



*Basic* cluster (0x0000):

- All global attributes

PICS:

- B.S, B.C
- B.S.Agm, B.C.Agm, B.S.Ago, B.C.Ago


#### 4.2.1.2 Required devices

| Designation | Symbol  | Description  |
|-------------|---|--|
| DUT         |  | Device under test implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster server or client.</li> </ul>   |
| TH          |  | Test harness implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster client or server, i.e. the opposite cluster instantiation as implemented on the DUT.</li> </ul> |

#### 4.2.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 4.2.1.4 Test preparation



| B-TC-01G: Global attributes |   |  |
|-----------------------------|---|--|
| Item                        | Preparation Step                                  | Observation  |
| P2                          | Power on TH and DUT.                              | TH and DUT are powered on.   |
| P3                          | Ensure TH and DUT are on the same ZigBee network. | Observe appropriate communication between TH, DUT and any other relevant node on the ZigBee network. |

--- End of test case B-TC-01G preparation ---



163 **4.2.1.5 Test procedure**

| <b>B-TC-01G: Global attributes</b> |                     |  |   |
|------------------------------------|---------------------|--|---|
| <b>Item</b>                        | <b>PICS</b>         | <b>Test Harness Step</b>   | <b>DUT pass Verification</b>  |
| 1                                  | B.S.Agm,<br>B.C.Agm | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read each mandatory global attribute of this cluster one at a time.                                   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing each requested attribute.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).  |
| 2a                                 | B.S.Agm,<br>B.C.Agm | TH unicasts a ZCL <i>write attributes</i> command frame to DUT to write the respective default value to each mandatory global attribute of this cluster one at a time. | DUT unicasts a ZCL <i>write attributes response</i> command frame to TH for each attribute.<br><br>If the access control of DUT is set to READ, the DUT response will indicate that the attribute write command was not a SUCCESS. If the access control of DUT is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.  |
| 2b                                 | B.S.Agm,<br>B.C.Agm | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read back each attribute written in step 2a.  | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

Continued...

| <b>B-TC-01G: Global attributes</b> |                     |   |  |
|------------------------------------|---------------------|---|--|
| <b>Item</b>                        | <b>PICS</b>         | <b>Test Harness Step</b>  | <b>DUT pass Verification</b>   |
| 3                                  | B.S.Ago,<br>B.C.Ago | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read each optional global attribute of this cluster one at a time.                                   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing each attribute.<br><br>If the DUT implements the attribute, the <i>Status</i> field will be equal to SUCCESS and the command will contain the requested attribute. If the DUT does not implement the attribute, the <i>Status</i> field will not be equal to SUCCESS.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s). |
| 4a                                 | B.S.Ago,<br>B.C.Ago | TH unicasts a ZCL <i>write attributes</i> command frame to DUT to write the respective default value to each optional global attribute of this cluster one at a time. | DUT unicasts a ZCL <i>write attributes response</i> command frame to TH for each attribute.<br><br>If the attribute is not implemented or the access control of DUT is set to READ, the DUT response will indicate that the attribute write command was not a SUCCESS. If the attribute is implemented and the access control of DUT is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.  |
| 4b                                 | B.S.Ago,<br>B.C.Ago | TH unicasts a ZCL <i>read attributes</i> command frame to DUT to read back each attribute written in step 4a.   | DUT unicasts a ZCL <i>read attributes response</i> command frame to TH containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back.  |

--- End of test case B-TC-01G ---

## 4.3 Server test cases

### 4.3.1 B-TC-01S: Attributes with server as DUT

This test case verifies the behavior of the non-global attributes of the *basic* cluster server.

In this test, the PICS notation B.S.Am represents the list of non-global attributes that are specified as being mandatory. Similarly, the PICS notation B.S.Ao represents the list of non-global attributes that are specified as being optional.

#### 4.3.1.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)



*Basic* cluster (0x0000):

- All non-global attributes

PICS:

- B.S,
- B.S.Am, B.S.Ao


#### 4.3.1.2 Required devices

| Designation   | Symbol  | Description  |
|---------------|---|--|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster client.</li> </ul> |
| DUT<br>SERVER |  | Device under test server: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster server.</li> </ul>         |

#### 4.3.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 4.3.1.4 Test preparation



| <b>B-TC-01S: Attributes with server as DUT</b> |   |  |
|--|---|--|
| Item   | Preparation Step  | Observation  |
| P2   | Power on TH CLIENT and DUT SERVER.                              | TH CLIENT and DUT SERVER are powered on.   |
| P3   | Ensure TH CLIENT and DUT SERVER are on the same ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case B-TC-01C preparation ---

190 **4.3.1.5 Test procedure**

| <b>B-TC-01S: Attributes with server as DUT</b> |             |   |   |
|--|-------------|---|---|
| <b>Item</b>                                    | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT pass Verification</b>  |
| 1  | B.S.Am      | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read each mandatory attribute of this cluster one at a time.                                   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing each requested attribute.<br><br>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).  |
| 2a   | B.S.Am      | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the respective default value to each mandatory attribute of this cluster one at a time. | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT for each attribute.<br><br>If the access control of DUT SERVER is set to READ, the DUT SERVER response will indicate that the attribute write command was not a SUCCESS. If the access control of DUT SERVER is set to READ/WRITE, the DUT SERVER response will indicate that the write command was a SUCCESS.                      |
| 2b   | B.S.Am      | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read back each attribute written in step 2a.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

Continued...

| <b>B-TC-01S: Attributes with server as DUT</b> |             |  |   |
|--|-------------|--|---|
| <b>Item</b>                                    | <b>PICS</b> | <b>Test Harness Step</b>   | <b>DUT pass Verification</b>  |
| 3  | B.S.Ao      | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read each optional attribute of this cluster one at a time.                                   | <p>DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing each attribute.</p> <p>If the DUT SERVER implements the attribute, the <i>Status</i> field will be equal to SUCCESS and the command will contain the requested attribute. If the DUT SERVER does not implement the attribute, the <i>Status</i> field will not be equal to SUCCESS.</p> <p>The data type in each command must match the value listed in the specification(s). The data value in each command for the attribute must fall within the valid range described in the specification(s).</p> |
| 4a   | B.S.Ao      | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to write the respective default value to each optional attribute of this cluster one at a time. | <p>DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT for each attribute.</p> <p>If the attribute is not implemented or the access control of DUT SERVER is set to READ, the DUT SERVER response will indicate that the attribute write command was not a SUCCESS. If the attribute is implemented and the access control of DUT SERVER is set to READ/WRITE, the DUT response will indicate that the write command was a SUCCESS.</p>   |

*Continued...*

| <b>B-TC-01S: Attributes with server as DUT</b> |             |   |   |
|--|-------------|---|---|
| <b>Item</b>                                    | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT pass Verification</b>  |
| 4b   | B.S.Ao      | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read back each attribute written in step 4a. | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT containing the requested attribute.<br><br>If the <i>Status</i> field of the <i>write attributes response</i> command frame was equal to SUCCESS, the updated value is read back. If the <i>Status</i> field of the <i>write attributes response</i> command frame was not equal to SUCCESS the value is not updated when read back. |

--- End of test case B-TC-01S ---

191

192

### 4.3.2 B-TC-02S: Secondary functionality with server as DUT

This test case verifies the secondary functionality of the *basic* cluster server.

#### 4.3.2.1 Scope

General:

- *Read attributes* command (0x00)
- *Read attributes response* command (0x01)
- *Write attributes* command (0x02)
- *Write attributes response* command (0x04)
- *Default response* command (0x0b)

*Basic* cluster (0x0000):

- *DeviceEnabled* attribute (0x0012)
- *Reset to factory defaults* command (0x00)



*Identify* cluster (0x0003):

- *IdentifyTime* attribute (0x0000)
- *Identify* command (0x00)

PICS:

- B.S
- B.S.A0012
- B.S.C00.Rsp
- I.S.A0000

#### 4.3.2.2 Required devices


| Designation   | Symbol  | Description   |
|---------------|---|---|
| TH<br>CLIENT  |  | Test harness client implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster client and</li> <li>• The <i>identify</i> cluster client.</li> </ul>      |
| DUT<br>SERVER |  | Device under test server implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster server and</li> <li>• The <i>identify</i> cluster client.</li> </ul> |



#### 4.3.2.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 4.3.2.4 Test preparation



| B-TC-02S: Secondary functionality with server as DUT |   |  |
|--|---|--|
| Item   | Preparation Step  | Observation  |
| P2   | Power on TH CLIENT and DUT SERVER.                              | TH CLIENT and DUT SERVER are powered on.   |
| P3   | Ensure TH CLIENT and DUT SERVER are on the same ZigBee network. | Observe appropriate communication between TH CLIENT, DUT SERVER and any other relevant node on the ZigBee network. |

--- End of test case B-TC-02S preparation ---

#### 4.3.2.5 Test procedure

| B-TC-02S: Secondary functionality with server as DUT  |             |   |  |
|---|-------------|---|--|
| Item  | PICS        | Test Harness Step   | DUT Pass Verification  |
| 1a  | I.S.A0000   | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to set the <i>IdentifyTime</i> attribute of the <i>Identify</i> cluster to 0x42.   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.   |
| 1b  | I.S.A0000   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>IdentifyTime</i> attribute.  | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>IdentifyTime</i> attribute has the value 0x42.   |
| 1c  | B.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>reset to factory defaults</i> command to DUT SERVER with the <i>disable default response</i> sub-field of the <i>frame control</i> field of the ZCL frame set to 0 (target must send a default response).                         | If the <i>reset to factory defaults</i> is not supported, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x81 (UNSUP_CLUSTER_COMMAND).<br>If the <i>reset to factory defaults</i> is supported, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS). |
| 1d  | I.S.A0000   | If a <i>default response</i> command was received with the <i>status</i> field equal to 0x00 (SUCCESS), TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>IdentifyTime</i> attribute of the <i>Identify</i> cluster. | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>IdentifyTime</i> attribute has the value 0x00.   |
| <b>Testing note:</b> Steps 2-7 only apply if the <i>DeviceEnabled</i> attribute is supported on DUT SERVER. |             |   |  |

Continued...

| <b>B-TC-02S: Secondary functionality with server as DUT</b> |             |   |   |
|---|-------------|---|---|
| <b>Item</b>   | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>  |
| 2   | -           | TH CLIENT unicasts a ZCL command, known to be supported on the DUT, other than a <i>read attributes</i> , <i>write attributes</i> or <i>identify</i> command frame to DUT SERVER. | DUT SERVER processes and responds to the command from TH CLIENT.  |
| 3a  | B.S.A0012   | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to set the <i>DeviceEnabled</i> attribute to 0x00.   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |
| 3b  | B.S.A0012   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>DeviceEnabled</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>DeviceEnabled</i> attribute has the value 0x00.   |
| 4   | B.S.A0012   | TH CLIENT unicasts the same ZCL command used in step 2 to DUT SERVER.   | DUT SERVER does nothing.  |
| 5a  | I.S.C00.Rsp | TH CLIENT unicasts a ZCL <i>identify</i> command frame to DUT SERVER, with the <i>identify time</i> field set to 0x003c (60s).  | If requested, DUT SERVER unicasts a ZCL <i>default response</i> command frame to TH CLIENT with the <i>status</i> field equal to 0x00 (SUCCESS).<br>DUT SERVER begins to identify itself. |
| 5b  | I.S.A0000   | After 40s, TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>IdentifyTime</i> attribute.   | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>IdentifyTime</i> attribute has a value approximately equal to 0x0014.                         |
| 6a  | B.S.A0012   | TH CLIENT unicasts a ZCL <i>write attributes</i> command frame to DUT SERVER to set the <i>DeviceEnabled</i> attribute to 0x01.   | DUT SERVER unicasts a ZCL <i>write attributes response</i> command frame to TH CLIENT.  |

Continued...

| <b>B-TC-02S: Secondary functionality with server as DUT</b> |             |   |   |
|---|-------------|---|---|
| <b>Item</b>   | <b>PICS</b> | <b>Test Harness Step</b>  | <b>DUT Pass Verification</b>  |
| 6b  | B.S.A0012   | TH CLIENT unicasts a ZCL <i>read attributes</i> command frame to DUT SERVER to read the <i>DeviceEnabled</i> attribute. | DUT SERVER unicasts a ZCL <i>read attributes response</i> command frame to TH CLIENT.<br><i>DeviceEnabled</i> attribute has the value 0x01. |
| 7   | -           | TH CLIENT unicasts the same ZCL command used in step 2 to DUT SERVER.   | DUT SERVER processes and responds to the command from TH CLIENT.  |

--- End of test case B-TC-02S ---

224  
225

## 4.4 Client test cases

### 4.4.1 B-TC-01C: Functionality with client as DUT

This case test verifies the functionality of the *basic* cluster client.

The DUT client SHALL be on the same network as a suitable server, provided by the user, and this device SHALL be used by the client to exercise its functionality. The test case uses the test harness to prompt the user, based on the declared PICS, to exercise the functionality of the *basic* cluster client and to verify the results. A sniffer tool SHALL be used to log the exercised functionality and to determine its validity.

In this test case, the PICS notation B.C.CdTx represents the list of commands that are declared as being transmitted by the DUT.

#### 4.4.1.1 Scope



*Basic* cluster (0x0000):

- *Reset to factory defaults* command (0x00)

PICS:

- B.C
- B.C.C00.Tx


#### 4.4.1.2 Required devices

| Designation   | Symbol  | Description   |
|---------------|---|---|
| DUT<br>CLIENT |  | Device under test client implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster client.</li> </ul> |
| SERVER        |  | Suitable server device implementing: <ul style="list-style-type: none"> <li>• The <i>basic</i> cluster server.</li> </ul>   |

#### 4.4.1.3 Initial conditions

| Item | Initial Conditions  |
|------|---|
| 1    | A packet sniffer shall be observing the communication over the air interface. |
| 2    | All devices are factory new and powered off until used.                       |

#### 4.4.1.4 Test preparation



| B-TC-01C: Functionality with client as DUT |  |   |
|--|--|---|
| Item                                       | Preparation Step   | Observation   |
| P1   | Power on the DUT CLIENT device and the SERVER device.                              | DUT CLIENT and SERVER are powered on.   |
| P2   | Ensure the DUT CLIENT device and the SERVER device are on the same ZigBee network. | Observe appropriate communication between DUT CLIENT, SERVER and any other relevant node on the ZigBee network. |

--- End of test case B-TC-01C preparation ---

252 **4.4.1.5 Test procedure**

| <b>B-TC-01C: Functionality with client as DUT</b> |             |  |   |
|---|-------------|--|---|
| <b>Item</b>                                       | <b>PICS</b> | <b>Test Harness Step</b>   | <b>DUT Pass Verification</b>  |
| 1   | -           | Test harness prompts the user with a list of commands, based on the declared PICS, which the DUT CLIENT indicates it can transmit. | None.   |
| 2   | B.C.Cd.Tx   | None.  | DUT CLIENT transmits correctly formed commands in any order and with application achievable values. This is verified using the sniffer log. |
| 3   | -           | Prompt the user to verify that the cluster commands listed in step 1 were transmitted during step 2.                               | During step 2, DUT CLIENT has transmitted every command listed by the test harness in step 1.   |
| 4   | -           | Prompt the user to verify that the cluster commands not listed in step 1 were not transmitted during step 2.                       | During step 2, DUT CLIENT has not transmitted any commands from this cluster that were not listed by the test harness in step 1.            |

--- End of test case B-TC-01C ---

253

## 5 Annex A: PICS to test case cross reference

### 5.1 Server

| PICS        | Test case |          |          |
|-------------|-----------|----------|----------|
|             | B-TC-01G  | B-TC-01S | B-TC-02S |
| B.S         | X         | X        | X        |
| B.S.A0000   |           | X        |          |
| B.S.A0001   |           | X        |          |
| B.S.A0002   |           | X        |          |
| B.S.A0003   |           | X        |          |
| B.S.A0004   |           | X        |          |
| B.S.A0005   |           | X        |          |
| B.S.A0006   |           | X        |          |
| B.S.A0007   |           | X        |          |
| B.S.A0010   |           | X        |          |
| B.S.A0011   |           | X        |          |
| B.S.A0012   |           | X        | X        |
| B.S.A0013   |           | X        |          |
| B.S.A0014   |           | X        |          |
| B.S.A4000   |           | X        |          |
| B.S.Afffd   | X         |          |          |
| B.S.C00.Rsp |           |          | X        |

### 5.2 Client

| PICS       | Test case |          |
|------------|-----------|----------|
|            | B-TC-01G  | B-TC-01C |
| B.C        | X         | X        |
| B.S.Afffd  | X         |          |
| B.C.C00.Tx |           | X        |